

## CHANNEL SETTINGS

Each channel on the Rocky Talkie is set to one of the 22 allowed FRS frequencies. The first 22 channels come preset with with no privacy code activated. The rest of the 128 channels are preset with a privacy code to make finding an open channel easier. Each channel's power settings is preset to conform with FRS regulations.

CHANNEL	FREQUENCY (MHZ)	POWER
1	462.5625	2 watt
2	462.5875	2 watt
3	462.6125	2 watt
4	462.6375	2 watt
5	462.6625	2 watt
6	462.6875	2 watt
7	462.7125	2 watt
8	467.5625	0.5 watt
9	467.5875	0.5 watt
10	467.6125	0.5 watt
11	467.6375	0.5 watt
12	467.6625	0.5 watt
13	467.6875	0.5 watt
14	467.7125	0.5 watt
15	462.5500	2 watt
16	462.5750	2 watt
17	462.6000	2 watt
18	462.6250	2 watt
19	462.6500	2 watt
20	462.6750	2 watt

CHANNEL	FREQUENCY (MHZ)	POWER
21	462.7000	2 watt
22	462.7250	2 watt
23	462.5625	2 watt
24	462.5875	2 watt
25	462.6125	2 watt
26	462.6375	2 watt
27	462.6625	2 watt
28	462.6875	2 watt
29	462.7125	2 watt
30	467.5625	0.5 watt
31	467.5875	0.5 watt
32	467.6125	0.5 watt
33	467.6375	0.5 watt
34	467.6625	0.5 watt
35	467.6875	0.5 watt
36	467.7125	0.5 watt
37	462.5500	2 watt
38	462.5750	2 watt
39	462.6000	2 watt
40	462.6250	2 watt
41	462.6500	2 watt
42	462.6750	2 watt
43	462.7000	2 watt
44	462.7250	2 watt
45	462.5625	2 watt
46	462.5875	2 watt
47	462.6125	2 watt
48	462.6375	2 watt

CHANNEL	FREQUENCY (MHZ)	POWER
49	462.6625	2 watt
50	462.6875	2 watt
51	462.7125	2 watt
52	467.5625	0.5 watt
53	467.5875	0.5 watt
54	467.6125	0.5 watt
55	467.6375	0.5 watt
56	467.6625	0.5 watt
57	467.6875	0.5 watt
58	467.7125	0.5 watt
59	462.5500	2 watt
60	462.5750	2 watt
61	462.6000	2 watt
62	462.6250	2 watt
63	462.6500	2 watt
64	462.6750	2 watt
65	462.7000	2 watt
66	462.7250	2 watt
67	462.5625	2 watt
68	462.5875	2 watt
69	462.6125	2 watt
70	462.6375	2 watt
71	462.6625	2 watt
72	462.6875	2 watt
73	462.7125	2 watt
74	467.5625	0.5 watt
75	467.5875	0.5 watt
76	467.6125	0.5 watt

CHANNEL	FREQUENCY (MHZ)	POWER
77	467.6375	0.5 watt
78	467.6625	0.5 watt
79	467.6875	0.5 watt
80	467.7125	0.5 watt
81	462.5500	2 watt
82	462.5750	2 watt
83	462.6000	2 watt
84	462.6250	2 watt
85	462.6500	2 watt
86	462.6750	2 watt
87	462.7000	2 watt
88	462.7250	2 watt
89	462.5625	2 watt
90	462.5875	2 watt
91	462.6125	2 watt
92	462.6375	2 watt
93	462.6625	2 watt
94	462.6875	2 watt
95	462.7125	2 watt
96	467.5625	0.5 watt
97	467.5875	0.5 watt
98	467.6125	0.5 watt
99	467.6375	0.5 watt
100	467.6625	0.5 watt
101	467.6875	0.5 watt
102	467.7125	0.5 watt
103	462.5500	2 watt
104	462.5750	2 watt

CHANNEL	FREQUENCY (MHZ)	POWER
105	462.6000	2 watt
106	462.6250	2 watt
107	462.6500	2 watt
108	462.6750	2 watt
109	462.7000	2 watt
110	462.7250	2 watt
111	462.5625	2 watt
112	462.5875	2 watt
113	462.6125	2 watt
114	462.6375	2 watt
115	462.6625	2 watt
116	462.6875	2 watt
117	462.7125	2 watt
118	467.5625	0.5 watt
119	467.5875	0.5 watt
120	467.6125	0.5 watt
121	467.6375	0.5 watt
122	467.6625	0.5 watt
123	467.6875	0.5 watt
124	467.7125	0.5 watt
125	462.5500	2 watt
126	462.5750	2 watt
127	462.6000	2 watt
128	462.6250	2 watt

## PRIVACY CODES

Rocky talkie privacy codes make it so that you can only hear other radios on the same frequency *and* privacy codes settings. For matching your privacy code to radios from most major radio brands, match both the channel number and privacy code number (also known as subchannel number). For other radios that do not conform to the these standards, use the below chart to find matching CTCSS and DCS settings.

ROCKY TALKIE / BCA / MOTOROLA	CTCSS FREQUENCY (HZ)
Off	0.0
1	67.0
2	71.9
3	74.4
4	77
5	79.7
6	82.5
7	85.4
8	88.5
9	91.5
10	94.8
11	97.4
12	100
13	103.5
14	107.2
15	110.9
16	114.8
17	118.8

<b>ROCKY TALKIE / BCA / MOTOROLA</b>	<b>CTCSS FREQUENCY (HZ)</b>
18	123
19	127.3
20	131.8
21	136.5
22	141.3
23	146.2
24	151.4
25	156.7
26	162.2
27	167.9
28	173.8
29	179.9
30	186.2
31	192.8
32	203.5
33	210.7
34	218.1
35	225.7
36	233.6
37	241.8
38	250.3

<b>ROCKY TALKIE / BCA / MOTOROLA</b>	<b>DCS (OCTAL)</b>
39	23
40	25
41	26
42	31
43	32
44	43
45	47
46	51
47	54
48	65
49	71
50	72
51	73
52	74
53	114
54	115
55	116
56	125
57	131
58	132
59	134
60	143
61	152
62	155
63	156
64	162
65	165
66	172



<b>ROCKY TALKIE</b> / BCA / MOTOROLA	<b>DCS</b> (OCTAL)
67	174
68	205
69	223
70	226
71	243
72	244
73	245
74	251
75	261
76	263
77	265
78	271
79	306
80	311
81	315
82	331
83	343
84	346
85	351
86	364
87	365
88	371
89	411
90	412
91	413
92	423
93	431
94	432

<b>ROCKY TALKIE / BCA / MOTOROLA</b>	<b>DCS (OCTAL)</b>
95	445
96	446
97	465
98	466
99	503
100	506
101	516
102	532
103	546
104	565
105	606
106	612
107	624
108	627
109	631
110	632
111	654
112	662
113	664
114	703
115	712
116	723
117	731
118	732
119	734
120	743
121	754